

# HYGIENE+ outlet

Ref. AT923024.50P

M24/100



## DESCRIPTION

**HYGIENE+ outlet**

**Ref. AT923024.50P**

HYGIENE+ free flow outlet M24/100 for basin taps/mixers.  
No grid or partitions in contact with water.  
No water stagnation is possible in internal parts reducing bacterial development.  
Made of Hostaform® reducing scale build-up.  
Chrome-plated brass ring.  
Supplied in packs of 50.  
Can only be installed on a tap or mixer with an already limited flow rate in order to maintain a good flow without splashing.

## ADVANTAGES



Smooth surface reduces bacterial development



Suitable for taps/mixers with limited flow rates

## TECHNICAL CHARACTERISTICS

**HYGIENE+ outlet - Ref. AT923024.50P**

Supply	M24/100
Finish	Hostaform® - laiton chromé
Norms	ACS

