

HYGIENE+ outlet

Ref. AT923022.50P

F22/100



DESCRIPTION

HYGIENE+ outlet

Ref. AT923022.50P

HYGIENE+ free flow outlet F22/100 for basin mixers and taps.
With no grid or partitions in contact with the water.
Water cannot stagnate in the internal part, reducing bacterial development.
Made from Hostaform® which reduces the build-up of scale.
Chrome-plated brass collar.
Supplied in packs of 50.
Sold individually.
Can only be installed on a mixer/tap with a restricted flow rate to ensure a good flow with no splashing.

ADVANTAGES



Smooth surface reduces bacterial development



Suitable for taps/mixers with limited flow rates

TECHNICAL CHARACTERISTICS

HYGIENE+ outlet - Ref. AT923022.50P

Supply	F22/100
Finish	Hostaform® - chrome-plated brass
Norms	ACS

