

# Auto-draining device

Ref. AT880

Automatically drains the shower head and flexible hose



## DESCRIPTION

**Auto-draining device**

**Ref. AT880**

Auto-draining device in chrome-plated brass which automatically drains the shower head and flexible shower hose.

Prevents water stagnation and reduces bacterial proliferation.

Body made from chrome-plated brass with an upstream purge.

Inlet F1/2" with filter to connect to the bottom outlet of the mixer.

Outlet M1/2" to connect to the flexible hose.

For use with a short flexible hose AT836T3.

## ADVANTAGES



Automatically drains shower head and flexible hose



Chrome-plated brass connector

## TECHNICAL CHARACTERISTICS

**Auto-draining device - Ref. AT880**

Connector	1/2"
Finish	Chrome-plated brass
Norms	ACS
Warranty	

