

FILT&SWAP inline filter

Ref. AT50672

Active charcoal



DESCRIPTION

FILT&SWAP inline filter

Ref. AT50672

FILT&SWAP active charcoal inline filter.
 Active charcoal: reduces taste, smell and chlorine in water.
 Filter cartridge can be replaced without changing the filter body.
 Capacity: 18,000L.
 Maximum lifespan: 6 months.
 Filtration flow rate: 9 lpm (with integrated flow restrictor), 14 lpm (without flow restrictor) at 3 bar.
 Materials: Body and filtration cartridge made of polypropylene. Filter cartridge plastic components made of ABS.
 Temperature: 4 - 38°C.
 Operating pressure: 0.5 - 10 bar.
 Connection type: Tube or G3/8".
 Compatible with and resistant to chemical shocks (active chlorine levels up to 100 ppm for 1 hour (cumulative total) and thermal shocks (70°C for 30 minutes).

ADVANTAGES



6 months

TECHNICAL CHARACTERISTICS

FILT&SWAP inline filter - Ref. AT50672

Supply	Tube or G3/8"
Length	235mm
Diameter	82mm
Lifespan	6 months
Norms	

